




1289 PE distribution x=200mm y=75mm




Example of a 99PE pulse




Example of a 94PE pulse




Example of a 300PE pulse




Example of a 277PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 200PE pulse




Example of a 143PE pulse




Example of a 116PE pulse




Example of a 108PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 76PE pulse




Example of a 64PE pulse




Example of a 286PE pulse




Example of a 273PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 202PE pulse




Example of a 212PE pulse




Example of a 120PE pulse




Example of a 115PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 60PE pulse




Example of a 58PE pulse




Example of a 275PE pulse




Example of a 220PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 171PE pulse




Example of a 169PE pulse




Example of a 80PE pulse




Example of a 76PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 29PE pulse




Example of a 35PE pulse




Example of a 328PE pulse




Example of a 279PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 118PE pulse




Example of a 133PE pulse




Example of a 103PE pulse




Example of a 87PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 85PE pulse




Example of a 88PE pulse




Example of a 228PE pulse




Example of a 198PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 104PE pulse




Example of a 89PE pulse




Example of a 94PE pulse




Example of a 57PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 57PE pulse




Example of a 54PE pulse




Example of a 198PE pulse




Example of a 138PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 86PE pulse




Example of a 77PE pulse




Example of a 64PE pulse




Example of a 61PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 60PE pulse




Example of a 60PE pulse




Example of a 137PE pulse




Example of a 149PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 89PE pulse




Example of a 87PE pulse




Example of a 52PE pulse




Example of a 53PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 61PE pulse




Example of a 23PE pulse




Example of a 199PE pulse




Example of a 191PE pulse




1289 PE distribution x=200mm y=75mm




Example of a 107PE pulse



Example of a 84PE pulse



Example of a 53PE pulse



Example of a 64PE pulse

