




810 PE distribution x=1500mm y=75mm




Example of a 34PE pulse




Example of a 47PE pulse




Example of a 77PE pulse




Example of a 82PE pulse




810 PE distribution x=1500mm y=75mm




Example of a 62PE pulse




Example of a 74PE pulse




Example of a 57PE pulse




Example of a 69PE pulse




810 PE distribution x=1500mm y=75mm




Example of a 77PE pulse




Example of a 90PE pulse




Example of a 55PE pulse




Example of a 71PE pulse




810 PE distribution x=1500mm y=75mm




Example of a 89PE pulse




Example of a 86PE pulse




Example of a 115PE pulse




Example of a 129PE pulse




810 PE distribution x=1500mm y=75mm




Example of a 32PE pulse




Example of a 56PE pulse




Example of a 102PE pulse




Example of a 94PE pulse




810 PE distribution x=1500mm y=75mm




Example of a 83PE pulse




Example of a 73PE pulse




Example of a 64PE pulse




Example of a 59PE pulse




810 PE distribution x=1500mm y=75mm




Example of a 84PE pulse




Example of a 77PE pulse




Example of a 69PE pulse




Example of a 77PE pulse




810 PE distribution x=1500mm y=75mm




Example of a 83PE pulse



Example of a 80PE pulse



Example of a 142PE pulse



Example of a 129PE pulse

