




1155 PE distribution x=1000mm y=75mm




Example of a 64PE pulse




Example of a 75PE pulse




Example of a 149PE pulse




Example of a 132PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 92PE pulse




Example of a 73PE pulse




Example of a 62PE pulse




Example of a 64PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 124PE pulse




Example of a 125PE pulse




Example of a 27PE pulse




Example of a 29PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 81PE pulse




Example of a 70PE pulse




Example of a 83PE pulse




Example of a 45PE pulse




1155 PE distribution x=1000mm y=75mm




1155 PE distribution x=1000mm y=75mm




1155 PE distribution x=1000mm y=75mm




Example of a 168PE pulse




Example of a 175PE pulse




Example of a 58PE pulse




Example of a 66PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 81PE pulse




Example of a 74PE pulse




Example of a 186PE pulse




Example of a 224PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 145PE pulse




Example of a 206PE pulse




Example of a 205PE pulse




Example of a 27PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 117PE pulse




Example of a 85PE pulse




Example of a 113PE pulse




Example of a 89PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 73PE pulse




Example of a 59PE pulse




Example of a 92PE pulse




Example of a 108PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 57PE pulse




Example of a 57PE pulse




Example of a 58PE pulse




Example of a 49PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 105PE pulse




Example of a 92PE pulse




Example of a 20PE pulse




Example of a 20PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 58PE pulse




Example of a 43PE pulse




Example of a 42PE pulse




Example of a 50PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 164PE pulse




Example of a 151PE pulse




Example of a 34PE pulse




Example of a 51PE pulse




1155 PE distribution x=1000mm y=75mm




Example of a 67PE pulse



Example of a 61PE pulse



Example of a 183PE pulse



Example of a 194PE pulse

