




815 PE distribution x=2000mm y=75mm




Example of a 46PE pulse




Example of a 53PE pulse




Example of a 48PE pulse




Example of a 46PE pulse




815 PE distribution x=2000mm y=75mm




Example of a 68PE pulse




Example of a 66PE pulse




Example of a 54PE pulse




Example of a 73PE pulse




815 PE distribution x=2000mm y=75mm




Example of a 54PE pulse




Example of a 74PE pulse




Example of a 61PE pulse




Example of a 77PE pulse




815 PE distribution x=2000mm y=75mm




Example of a 57PE pulse




Example of a 69PE pulse




Example of a 75PE pulse




Example of a 64PE pulse




815 PE distribution x=2000mm y=75mm




Example of a 26PE pulse




Example of a 38PE pulse




Example of a 52PE pulse




Example of a 50PE pulse




815 PE distribution x=2000mm y=75mm




Example of a 62PE pulse




Example of a 64PE pulse




Example of a 67PE pulse




Example of a 85PE pulse




815 PE distribution x=2000mm y=75mm




Example of a 49PE pulse




Example of a 59PE pulse




Example of a 53PE pulse




Example of a 60PE pulse




815 PE distribution x=2000mm y=75mm




Example of a 63PE pulse



Example of a 49PE pulse



Example of a 58PE pulse



Example of a 53PE pulse

