




709 PE distribution x=70mm y=25mm




Example of a 47PE pulse




Example of a 43PE pulse




Example of a 52PE pulse




Example of a 40PE pulse




709 PE distribution x=70mm y=25mm




Example of a 82PE pulse




Example of a 239PE pulse




Example of a 164PE pulse




Example of a 179PE pulse




709 PE distribution x=70mm y=25mm




Example of a 57PE pulse




Example of a 39PE pulse




Example of a 42PE pulse




Example of a 34PE pulse




709 PE distribution x=70mm y=25mm




Example of a 79PE pulse




Example of a 78PE pulse




Example of a 53PE pulse




Example of a 25PE pulse




709 PE distribution x=70mm y=25mm




Example of a 47PE pulse




Example of a 54PE pulse




Example of a 40PE pulse




Example of a 38PE pulse




709 PE distribution x=70mm y=25mm




Example of a 64PE pulse




Example of a 87PE pulse




Example of a 81PE pulse




Example of a 118PE pulse




709 PE distribution x=70mm y=25mm




Example of a 35PE pulse




Example of a 32PE pulse




Example of a 46PE pulse




Example of a 30PE pulse




709 PE distribution x=70mm y=25mm




Example of a 29PE pulse




Example of a 27PE pulse




Example of a 121PE pulse




Example of a 116PE pulse




709 PE distribution x=70mm y=25mm




Example of a 100PE pulse




Example of a 102PE pulse




Example of a 85PE pulse




Example of a 92PE pulse




709 PE distribution x=70mm y=25mm




Example of a 158PE pulse




Example of a 145PE pulse




Example of a 35PE pulse




Example of a 30PE pulse




709 PE distribution x=70mm y=25mm




Example of a 175PE pulse




Example of a 82PE pulse




Example of a 57PE pulse




Example of a 71PE pulse




709 PE distribution x=70mm y=25mm




Example of a 100PE pulse




Example of a 148PE pulse




Example of a 143PE pulse




Example of a 61PE pulse




709 PE distribution x=70mm y=25mm




Example of a 79PE pulse




Example of a 95PE pulse




Example of a 84PE pulse




Example of a 71PE pulse




709 PE distribution x=70mm y=25mm




Example of a 35PE pulse




Example of a 31PE pulse




Example of a 148PE pulse




Example of a 160PE pulse




709 PE distribution x=70mm y=25mm




Example of a 35PE pulse




Example of a 21PE pulse




Example of a 57PE pulse




Example of a 49PE pulse




709 PE distribution x=70mm y=25mm




Example of a 54PE pulse



Example of a 40PE pulse



Example of a 179PE pulse



Example of a 213PE pulse

