




1171 PE distribution x=1000mm y=75mm




Example of a 131PE pulse




Example of a 105PE pulse




Example of a 91PE pulse




Example of a 25PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 101PE pulse




Example of a 116PE pulse




Example of a 96PE pulse




Example of a 80PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 165PE pulse




Example of a 141PE pulse




Example of a 93PE pulse




Example of a 119PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 185PE pulse




Example of a 178PE pulse




Example of a 132PE pulse




Example of a 99PE pulse




1171 PE distribution x=1000mm y=75mm




1171 PE distribution x=1000mm y=75mm




1171 PE distribution x=1000mm y=75mm




Example of a 100PE pulse




Example of a 111PE pulse




Example of a 87PE pulse




Example of a 105PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 131PE pulse




Example of a 176PE pulse




Example of a 148PE pulse




Example of a 151PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 198PE pulse




Example of a 220PE pulse




Example of a 201PE pulse




Example of a 248PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 185PE pulse




Example of a 172PE pulse




Example of a 215PE pulse




Example of a 195PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 112PE pulse




Example of a 129PE pulse




Example of a 145PE pulse




Example of a 20PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 96PE pulse




Example of a 85PE pulse




Example of a 76PE pulse




Example of a 87PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 145PE pulse




Example of a 138PE pulse




Example of a 140PE pulse




Example of a 117PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 135PE pulse




Example of a 138PE pulse




Example of a 132PE pulse




Example of a 114PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 123PE pulse




Example of a 93PE pulse




Example of a 112PE pulse




Example of a 79PE pulse




1171 PE distribution x=1000mm y=75mm




Example of a 104PE pulse



Example of a 135PE pulse



Example of a 129PE pulse



Example of a 116PE pulse

