




# 1012 PE distribution x=300mm y=75mm




Example of a 105PE pulse




Example of a 126PE pulse




Example of a 119PE pulse




Example of a 123PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 174PE pulse




Example of a 137PE pulse




Example of a 100PE pulse




Example of a 118PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 72PE pulse




Example of a 90PE pulse




Example of a 79PE pulse




Example of a 69PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 100PE pulse




Example of a 83PE pulse




Example of a 92PE pulse




Example of a 108PE pulse




# 1012 PE distribution x=300mm y=75mm




# 1012 PE distribution x=300mm y=75mm




# 1012 PE distribution x=300mm y=75mm




Example of a 52PE pulse




Example of a 74PE pulse




Example of a 78PE pulse




Example of a 61PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 84PE pulse




Example of a 99PE pulse



Example of a 74PE pulse




Example of a 68PE pulse







# 1012 PE distribution x=300mm y=75mm




Example of a 51PE pulse




Example of a 62PE pulse




Example of a 81PE pulse




Example of a 49PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 97PE pulse




Example of a 75PE pulse




Example of a 71PE pulse




Example of a 45PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 43PE pulse




Example of a 59PE pulse




Example of a 52PE pulse




Example of a 39PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 44PE pulse




Example of a 35PE pulse




Example of a 44PE pulse




Example of a 54PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 48PE pulse




Example of a 67PE pulse




Example of a 90PE pulse




Example of a 97PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 113PE pulse




Example of a 72PE pulse




Example of a 111PE pulse




Example of a 88PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 31PE pulse




Example of a 67PE pulse




Example of a 59PE pulse




Example of a 40PE pulse




# 1012 PE distribution x=300mm y=75mm




Example of a 48PE pulse



Example of a 47PE pulse



Example of a 36PE pulse



Example of a 53PE pulse

