




1157 PE distribution x=1000mm y=25mm




Example of a 102PE pulse




Example of a 77PE pulse




Example of a 219PE pulse




Example of a 204PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 128PE pulse




Example of a 263PE pulse




Example of a 63PE pulse




Example of a 82PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 66PE pulse




Example of a 79PE pulse




Example of a 70PE pulse




Example of a 259PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 70PE pulse




Example of a 69PE pulse




Example of a 76PE pulse




Example of a 86PE pulse




1157 PE distribution x=1000mm y=25mm




1157 PE distribution x=1000mm y=25mm




# 1157 PE distribution x=1000mm y=25mm




Example of a 73PE pulse




Example of a 71PE pulse




Example of a 219PE pulse




Example of a 239PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 41PE pulse




Example of a 54PE pulse



Example of a 91PE pulse




Example of a 126PE pulse







# 1157 PE distribution x=1000mm y=25mm




Example of a 102PE pulse




Example of a 99PE pulse




Example of a 89PE pulse




Example of a 105PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 118PE pulse




Example of a 97PE pulse




Example of a 108PE pulse




Example of a 138PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 75PE pulse




Example of a 76PE pulse




Example of a 170PE pulse




Example of a 210PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 247PE pulse




Example of a 224PE pulse




Example of a 50PE pulse




Example of a 66PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 84PE pulse




Example of a 76PE pulse




Example of a 77PE pulse




Example of a 49PE pulse




1157 PE distribution x=1000mm y=25mm




Example of a 49PE pulse




Example of a 49PE pulse




Example of a 50PE pulse




Example of a 66PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 75PE pulse




Example of a 62PE pulse




Example of a 207PE pulse




Example of a 197PE pulse




# 1157 PE distribution x=1000mm y=25mm




Example of a 41PE pulse



Example of a 52PE pulse



Example of a 86PE pulse



Example of a 90PE pulse

