




# 715 PE distribution x=30mm y=25mm




Example of a 37PE pulse




Example of a 23PE pulse




Example of a 34PE pulse




Example of a 33PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 51PE pulse




Example of a 64PE pulse




Example of a 127PE pulse




Example of a 99PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 47PE pulse




Example of a 27PE pulse




Example of a 42PE pulse




Example of a 24PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 37PE pulse




Example of a 38PE pulse




Example of a 113PE pulse




Example of a 94PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 39PE pulse




Example of a 22PE pulse




Example of a 28PE pulse




Example of a 27PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 34PE pulse




Example of a 22PE pulse




Example of a 144PE pulse




Example of a 161PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 24PE pulse




Example of a 24PE pulse




Example of a 23PE pulse




Example of a 25PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 117PE pulse




Example of a 142PE pulse



Example of a 86PE pulse




Example of a 74PE pulse







# 715 PE distribution x=30mm y=25mm




Example of a 88PE pulse




Example of a 60PE pulse




Example of a 66PE pulse




Example of a 61PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 72PE pulse




Example of a 105PE pulse




Example of a 223PE pulse




Example of a 262PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 80PE pulse




Example of a 51PE pulse




Example of a 64PE pulse




Example of a 64PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 82PE pulse




Example of a 111PE pulse




Example of a 175PE pulse




Example of a 157PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 76PE pulse




Example of a 76PE pulse




Example of a 83PE pulse




Example of a 79PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 41PE pulse




Example of a 30PE pulse




Example of a 203PE pulse




Example of a 205PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 38PE pulse




Example of a 40PE pulse




Example of a 30PE pulse




Example of a 47PE pulse




# 715 PE distribution x=30mm y=25mm




Example of a 153PE pulse



Example of a 179PE pulse



Example of a 114PE pulse



Example of a 116PE pulse

