




828 PE distribution x=1500mm y=75mm




Example of a 39PE pulse




Example of a 51PE pulse




Example of a 77PE pulse




Example of a 96PE pulse




828 PE distribution x=1500mm y=75mm




Example of a 54PE pulse




Example of a 59PE pulse




Example of a 87PE pulse




Example of a 95PE pulse




828 PE distribution x=1500mm y=75mm




Example of a 88PE pulse




Example of a 80PE pulse




Example of a 69PE pulse




Example of a 93PE pulse




828 PE distribution x=1500mm y=75mm




Example of a 67PE pulse




Example of a 55PE pulse




Example of a 85PE pulse




Example of a 63PE pulse




828 PE distribution x=1500mm y=75mm




Example of a 43PE pulse




Example of a 48PE pulse




Example of a 59PE pulse




Example of a 87PE pulse




828 PE distribution x=1500mm y=75mm




Example of a 70PE pulse




Example of a 51PE pulse




Example of a 90PE pulse




Example of a 88PE pulse




828 PE distribution x=1500mm y=75mm




Example of a 79PE pulse




Example of a 70PE pulse




Example of a 64PE pulse




Example of a 80PE pulse




828 PE distribution x=1500mm y=75mm




Example of a 67PE pulse



Example of a 62PE pulse



Example of a 56PE pulse



Example of a 77PE pulse

