




1162 PE distribution x=0mm y=0mm




Example of a 175PE pulse




Example of a 175PE pulse




Example of a 124PE pulse




Example of a 94PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 91PE pulse




Example of a 79PE pulse




Example of a 95PE pulse




Example of a 83PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 81PE pulse




Example of a 64PE pulse




Example of a 97PE pulse




Example of a 91PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 91PE pulse




Example of a 85PE pulse




Example of a 116PE pulse




Example of a 93PE pulse




1162 PE distribution x=0mm y=0mm




1162 PE distribution x=0mm y=0mm




1162 PE distribution x=0mm y=0mm




Example of a 96PE pulse




Example of a 93PE pulse




Example of a 57PE pulse




Example of a 94PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 86PE pulse




Example of a 73PE pulse




Example of a 106PE pulse




Example of a 54PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 161PE pulse




Example of a 158PE pulse




Example of a 157PE pulse




Example of a 107PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 131PE pulse




Example of a 113PE pulse




Example of a 189PE pulse




Example of a 153PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 150PE pulse




Example of a 186PE pulse




Example of a 100PE pulse




Example of a 95PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 64PE pulse




Example of a 72PE pulse




Example of a 99PE pulse




Example of a 94PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 102PE pulse




Example of a 84PE pulse




Example of a 99PE pulse




Example of a 71PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 86PE pulse




Example of a 59PE pulse




Example of a 105PE pulse




Example of a 73PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 79PE pulse




Example of a 90PE pulse




Example of a 60PE pulse




Example of a 77PE pulse




1162 PE distribution x=0mm y=0mm




Example of a 79PE pulse



Example of a 82PE pulse



Example of a 105PE pulse



Example of a 70PE pulse

