




# 1282 PE distribution x=100mm y=75mm




Example of a 100PE pulse




Example of a 121PE pulse




Example of a 197PE pulse




Example of a 196PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 139PE pulse




Example of a 94PE pulse




Example of a 273PE pulse




Example of a 269PE pulse




1282 PE distribution x=100mm y=75mm




1282 PE distribution x=100mm y=75mm




1282 PE distribution x=100mm y=75mm




1282 PE distribution x=100mm y=75mm




# 1282 PE distribution x=100mm y=75mm




Example of a 93PE pulse




Example of a 81PE pulse




Example of a 46PE pulse




Example of a 42PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 93PE pulse




Example of a 87PE pulse



Example of a 74PE pulse




Example of a 90PE pulse







# 1282 PE distribution x=100mm y=75mm




Example of a 59PE pulse




Example of a 60PE pulse




Example of a 106PE pulse




Example of a 105PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 49PE pulse




Example of a 50PE pulse




Example of a 169PE pulse




Example of a 161PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 47PE pulse




Example of a 59PE pulse




Example of a 67PE pulse




Example of a 72PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 61PE pulse




Example of a 63PE pulse




Example of a 131PE pulse




Example of a 151PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 293PE pulse




Example of a 352PE pulse




Example of a 304PE pulse




Example of a 372PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 77PE pulse




Example of a 68PE pulse




Example of a 166PE pulse




Example of a 126PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 102PE pulse




Example of a 54PE pulse




Example of a 64PE pulse




Example of a 24PE pulse




# 1282 PE distribution x=100mm y=75mm




Example of a 60PE pulse



Example of a 53PE pulse



Example of a 38PE pulse



Example of a 50PE pulse

