




1288 PE distribution x=750mm y=75mm




Example of a 78PE pulse




Example of a 112PE pulse




Example of a 55PE pulse




Example of a 67PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 112PE pulse




Example of a 94PE pulse




Example of a 95PE pulse




Example of a 96PE pulse




1288 PE distribution x=750mm y=75mm




1288 PE distribution x=750mm y=75mm




1288 PE distribution x=750mm y=75mm




1288 PE distribution x=750mm y=75mm




1288 PE distribution x=750mm y=75mm




Example of a 110PE pulse




Example of a 144PE pulse




Example of a 224PE pulse




Example of a 174PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 175PE pulse




Example of a 189PE pulse




Example of a 65PE pulse




Example of a 64PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 93PE pulse




Example of a 73PE pulse




Example of a 28PE pulse




Example of a 36PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 79PE pulse




Example of a 79PE pulse




Example of a 72PE pulse




Example of a 74PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 113PE pulse




Example of a 97PE pulse




Example of a 85PE pulse




Example of a 24PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 52PE pulse




Example of a 54PE pulse




Example of a 88PE pulse




Example of a 84PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 147PE pulse




Example of a 174PE pulse




Example of a 157PE pulse




Example of a 198PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 125PE pulse




Example of a 107PE pulse




Example of a 95PE pulse




Example of a 74PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 93PE pulse




Example of a 179PE pulse




Example of a 177PE pulse




Example of a 22PE pulse




1288 PE distribution x=750mm y=75mm




Example of a 182PE pulse



Example of a 158PE pulse



Example of a 55PE pulse



Example of a 63PE pulse

