




# 713 PE distribution x=40mm y=25mm




Example of a 48PE pulse




Example of a 45PE pulse




Example of a 31PE pulse




Example of a 48PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 111PE pulse




Example of a 22PE pulse




Example of a 39PE pulse




Example of a 30PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 42PE pulse




Example of a 22PE pulse




Example of a 75PE pulse




Example of a 85PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 63PE pulse




Example of a 256PE pulse




Example of a 28PE pulse




Example of a 34PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 28PE pulse




Example of a 45PE pulse




Example of a 88PE pulse




Example of a 96PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 90PE pulse




Example of a 91PE pulse




Example of a 98PE pulse




Example of a 99PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 24PE pulse




Example of a 25PE pulse




Example of a 22PE pulse




Example of a 26PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 53PE pulse




Example of a 78PE pulse



Example of a 169PE pulse




Example of a 173PE pulse







# 713 PE distribution x=40mm y=25mm




Example of a 80PE pulse




Example of a 73PE pulse




Example of a 89PE pulse




Example of a 108PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 182PE pulse




Example of a 174PE pulse




Example of a 70PE pulse




Example of a 73PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 56PE pulse




Example of a 64PE pulse




Example of a 67PE pulse




Example of a 147PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 82PE pulse




Example of a 55PE pulse




Example of a 57PE pulse




Example of a 49PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 82PE pulse




Example of a 79PE pulse




Example of a 170PE pulse




Example of a 185PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 112PE pulse




Example of a 122PE pulse




Example of a 129PE pulse




Example of a 148PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 32PE pulse




Example of a 30PE pulse




Example of a 33PE pulse




Example of a 52PE pulse




# 713 PE distribution x=40mm y=25mm




Example of a 271PE pulse



Example of a 257PE pulse



Example of a 30PE pulse



Example of a 30PE pulse

