




# 1257 PE distribution x=2250mm y=25mm




Example of a 80PE pulse




Example of a 90PE pulse




Example of a 81PE pulse




Example of a 84PE pulse




# 1257 PE distribution x=2250mm y=25mm




Example of a 271PE pulse




Example of a 280PE pulse




Example of a 100PE pulse




Example of a 132PE pulse




1257 PE distribution x=2250mm y=25mm




# 1257 PE distribution x=2250mm y=25mm




1257 PE distribution x=2250mm y=25mm




1257 PE distribution x=2250mm y=25mm




1257 PE distribution x=2250mm y=25mm




Example of a 59PE pulse




Example of a 48PE pulse




Example of a 92PE pulse




Example of a 112PE pulse




1257 PE distribution x=2250mm y=25mm




Example of a 199PE pulse




Example of a 234PE pulse



Example of a 38PE pulse




Example of a 64PE pulse







# 1257 PE distribution x=2250mm y=25mm




Example of a 124PE pulse




Example of a 115PE pulse




Example of a 102PE pulse




Example of a 95PE pulse




# 1257 PE distribution x=2250mm y=25mm




Example of a 84PE pulse




Example of a 310PE pulse




Example of a 134PE pulse




Example of a 165PE pulse




# 1257 PE distribution x=2250mm y=25mm




Example of a 73PE pulse




Example of a 74PE pulse




Example of a 92PE pulse




Example of a 86PE pulse




# 1257 PE distribution x=2250mm y=25mm




Example of a 126PE pulse




Example of a 91PE pulse




Example of a 62PE pulse




Example of a 83PE pulse




# 1257 PE distribution x=2250mm y=25mm




Example of a 140PE pulse




Example of a 164PE pulse




Example of a 102PE pulse




Example of a 79PE pulse




# 1257 PE distribution x=2250mm y=25mm




Example of a 165PE pulse




Example of a 131PE pulse




Example of a 89PE pulse




Example of a 88PE pulse




# 1257 PE distribution x=2250mm y=25mm




Example of a 79PE pulse




Example of a 51PE pulse




Example of a 121PE pulse




Example of a 120PE pulse




# 1257 PE distribution x=2250mm y=25mm




Example of a 251PE pulse



Example of a 277PE pulse



Example of a 73PE pulse



Example of a 71PE pulse

