




# 1267 PE distribution x=200mm y=25mm




Example of a 153PE pulse




Example of a 168PE pulse




Example of a 147PE pulse




Example of a 126PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 202PE pulse




Example of a 144PE pulse




Example of a 112PE pulse




Example of a 113PE pulse




1267 PE distribution x=200mm y=25mm




1267 PE distribution x=200mm y=25mm




1267 PE distribution x=200mm y=25mm




Example of a 29PE pulse




Example of a 25PE pulse




Example of a 20PE pulse




Example of a 25PE pulse




1267 PE distribution x=200mm y=25mm




# 1267 PE distribution x=200mm y=25mm




Example of a  $^{131}\text{I}$  pulse




Example of a  $^{134}\text{I}$  pulse




Example of a 93PE pulse




Example of a 88PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 214PE pulse




Example of a 187PE pulse



Example of a 135PE pulse




Example of a 144PE pulse







# 1267 PE distribution x=200mm y=25mm




Example of a 92PE pulse




Example of a 87PE pulse




Example of a 94PE pulse




Example of a 86PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 106PE pulse




Example of a 107PE pulse




Example of a 64PE pulse




Example of a 87PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 73PE pulse




Example of a 70PE pulse




Example of a 70PE pulse




Example of a 74PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 84PE pulse




Example of a 89PE pulse




Example of a 121PE pulse




Example of a 146PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 80PE pulse




Example of a 86PE pulse




Example of a 83PE pulse




Example of a 85PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 125PE pulse




Example of a 155PE pulse




Example of a 100PE pulse




Example of a 101PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 85PE pulse




Example of a 87PE pulse




Example of a 51PE pulse




Example of a 40PE pulse




# 1267 PE distribution x=200mm y=25mm




Example of a 122PE pulse



Example of a 105PE pulse



Example of a 96PE pulse



Example of a 95PE pulse

