




1055 PE distribution x=200mm y=75mm




Example of a 124PE pulse




Example of a 83PE pulse




Example of a 69PE pulse




Example of a 80PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 102PE pulse




Example of a 102PE pulse




Example of a 137PE pulse




Example of a 146PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 166PE pulse




Example of a 154PE pulse




Example of a 100PE pulse




Example of a 115PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 89PE pulse




Example of a 68PE pulse




Example of a 198PE pulse




Example of a 208PE pulse




1055 PE distribution x=200mm y=75mm




1055 PE distribution x=200mm y=75mm




1055 PE distribution x=200mm y=75mm




Example of a 69PE pulse




Example of a 77PE pulse




Example of a 120PE pulse




Example of a 103PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 133PE pulse




Example of a 132PE pulse




Example of a 173PE pulse




Example of a 196PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 97PE pulse




Example of a 73PE pulse




Example of a 60PE pulse




Example of a 103PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 105PE pulse




Example of a 68PE pulse




Example of a 84PE pulse




Example of a 101PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 67PE pulse




Example of a 34PE pulse




Example of a 41PE pulse




Example of a 42PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 63PE pulse




Example of a 56PE pulse




Example of a 65PE pulse




Example of a 82PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 44PE pulse




Example of a 72PE pulse




Example of a 207PE pulse




Example of a 239PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 48PE pulse




Example of a 35PE pulse




Example of a 125PE pulse




Example of a 134PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 53PE pulse




Example of a 58PE pulse




Example of a 56PE pulse




Example of a 44PE pulse




1055 PE distribution x=200mm y=75mm




Example of a 65PE pulse



Example of a 60PE pulse



Example of a 125PE pulse



Example of a 101PE pulse

