




1160 PE distribution x=1000mm y=25mm




Example of a 100PE pulse




Example of a 77PE pulse




Example of a 84PE pulse




Example of a 66PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 74PE pulse




Example of a 65PE pulse




Example of a 231PE pulse




Example of a 239PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 86PE pulse




Example of a 94PE pulse




Example of a 85PE pulse




Example of a 66PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 287PE pulse




Example of a 298PE pulse




Example of a 161PE pulse




Example of a 188PE pulse




1160 PE distribution x=1000mm y=25mm




1160 PE distribution x=1000mm y=25mm




1160 PE distribution x=1000mm y=25mm




Example of a 71PE pulse




Example of a 54PE pulse




Example of a 47PE pulse




Example of a 77PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 137PE pulse




Example of a 167PE pulse




Example of a 138PE pulse




Example of a 185PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 108PE pulse




Example of a 128PE pulse




Example of a 114PE pulse




Example of a 125PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 116PE pulse




Example of a 133PE pulse




Example of a 126PE pulse




Example of a 117PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 86PE pulse




Example of a 91PE pulse




Example of a 66PE pulse




Example of a 72PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 80PE pulse




Example of a 71PE pulse




Example of a 70PE pulse




Example of a 224PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 82PE pulse




Example of a 78PE pulse




Example of a 92PE pulse




Example of a 91PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 29PE pulse




Example of a 87PE pulse




Example of a 60PE pulse




Example of a 144PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 55PE pulse




Example of a 69PE pulse




Example of a 60PE pulse




Example of a 45PE pulse




1160 PE distribution x=1000mm y=25mm




Example of a 131PE pulse



Example of a 147PE pulse



Example of a 155PE pulse



Example of a 169PE pulse

