




1272 PE distribution x=20mm y=25mm




Example of a 104PE pulse




Example of a 69PE pulse




Example of a 66PE pulse




Example of a 140PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 66PE pulse




Example of a 87PE pulse




Example of a 158PE pulse




Example of a 239PE pulse




1272 PE distribution x=20mm y=25mm




1272 PE distribution x=20mm y=25mm




1272 PE distribution x=20mm y=25mm




Example of a 29PE pulse




Example of a 21PE pulse




Example of a 20PE pulse




Example of a 23PE pulse




1272 PE distribution x=20mm y=25mm




1272 PE distribution x=20mm y=25mm




Example of a 94PE pulse




Example of a 62PE pulse




Example of a 47PE pulse




Example of a 80PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 50PE pulse




Example of a 52PE pulse




Example of a 80PE pulse




Example of a 95PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 43PE pulse




Example of a 29PE pulse




Example of a 29PE pulse




Example of a 56PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 40PE pulse




Example of a 50PE pulse




Example of a 87PE pulse




Example of a 129PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 47PE pulse




Example of a 21PE pulse




Example of a 20PE pulse




Example of a 31PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 47PE pulse




Example of a 68PE pulse




Example of a 40PE pulse




Example of a 66PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 42PE pulse




Example of a 33PE pulse




Example of a 29PE pulse




Example of a 51PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 202PE pulse




Example of a 200PE pulse




Example of a 118PE pulse




Example of a 143PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 40PE pulse




Example of a 48PE pulse




Example of a 38PE pulse




Example of a 44PE pulse




1272 PE distribution x=20mm y=25mm




Example of a 37PE pulse



Example of a 35PE pulse



Example of a 46PE pulse



Example of a 51PE pulse

