




1339 PE distribution x=1000mm y=25mm




Example of a 82PE pulse




Example of a 72PE pulse




Example of a 215PE pulse




Example of a 214PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 128PE pulse




Example of a 127PE pulse




Example of a 112PE pulse




Example of a 82PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 98PE pulse




Example of a 55PE pulse




Example of a 60PE pulse




Example of a 49PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 41PE pulse




Example of a 49PE pulse




Example of a 43PE pulse




Example of a 51PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 52PE pulse




Example of a 68PE pulse




Example of a 47PE pulse




Example of a 63PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 113PE pulse




Example of a 49PE pulse




Example of a 58PE pulse




Example of a 300PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 60PE pulse




Example of a 49PE pulse




Example of a 59PE pulse




Example of a 68PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 139PE pulse




Example of a 95PE pulse




Example of a 166PE pulse




Example of a 216PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 67PE pulse




Example of a 64PE pulse




Example of a 159PE pulse




Example of a 177PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 128PE pulse




Example of a 103PE pulse




Example of a 63PE pulse




Example of a 58PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 53PE pulse




Example of a 47PE pulse




Example of a 46PE pulse




Example of a 31PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 36PE pulse




Example of a 41PE pulse




Example of a 34PE pulse




Example of a 43PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 54PE pulse




Example of a 40PE pulse




Example of a 37PE pulse




Example of a 30PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 48PE pulse




Example of a 29PE pulse




Example of a 296PE pulse




Example of a 271PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 53PE pulse




Example of a 53PE pulse




Example of a 26PE pulse




Example of a 38PE pulse




1339 PE distribution x=1000mm y=25mm




Example of a 58PE pulse



Example of a 63PE pulse



Example of a 88PE pulse



Example of a 133PE pulse

