




# 1006 PE distribution x=1750mm y=75mm




Example of a 92PE pulse




Example of a 86PE pulse




Example of a 170PE pulse




Example of a 223PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 95PE pulse




Example of a 78PE pulse




Example of a 104PE pulse




Example of a 69PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 69PE pulse




Example of a 63PE pulse




Example of a 63PE pulse




Example of a 285PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 74PE pulse




Example of a 44PE pulse




Example of a 53PE pulse




Example of a 61PE pulse




# 1006 PE distribution x=1750mm y=75mm




# 1006 PE distribution x=1750mm y=75mm




# 1006 PE distribution x=1750mm y=75mm




Example of a 51PE pulse




Example of a 31PE pulse




Example of a 63PE pulse




Example of a 45PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 76PE pulse




Example of a 88PE pulse



Example of a 76PE pulse




Example of a 48PE pulse







# 1006 PE distribution x=1750mm y=75mm




Example of a 91PE pulse




Example of a 87PE pulse




Example of a 82PE pulse




Example of a 242PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 89PE pulse




Example of a 74PE pulse




Example of a 107PE pulse




Example of a 109PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 64PE pulse




Example of a 85PE pulse




Example of a 70PE pulse




Example of a 64PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 82PE pulse




Example of a 54PE pulse




Example of a 76PE pulse




Example of a 56PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 74PE pulse




Example of a 109PE pulse




Example of a 95PE pulse




Example of a 453PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 108PE pulse




Example of a 97PE pulse




Example of a 80PE pulse




Example of a 77PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 47PE pulse




Example of a 55PE pulse




Example of a 79PE pulse




Example of a 52PE pulse




# 1006 PE distribution x=1750mm y=75mm




Example of a 78PE pulse



Example of a 81PE pulse



Example of a 63PE pulse



Example of a 52PE pulse

