




837 PE distribution x=300mm y=75mm




Example of a 41PE pulse




Example of a 47PE pulse




Example of a 245PE pulse




Example of a 186PE pulse




837 PE distribution x=300mm y=75mm




Example of a 369PE pulse




Example of a 67PE pulse




Example of a 80PE pulse




Example of a 158PE pulse




837 PE distribution x=300mm y=75mm




Example of a 48PE pulse




Example of a 55PE pulse




Example of a 53PE pulse




Example of a 71PE pulse




837 PE distribution x=300mm y=75mm




Example of a 252PE pulse




Example of a 53562177PE pulse




Example of a 95PE pulse




Example of a 633221328PE pulse




837 PE distribution x=300mm y=75mm




Example of a 73PE pulse




Example of a 229PE pulse




Example of a 199328209PE pulse




Example of a 463587480PE pulse




837 PE distribution x=300mm y=75mm




Example of a 2130297888PE pulse




Example of a 977519541PE pulse




Example of a 116PE pulse




Example of a 83PE pulse




837 PE distribution x=300mm y=75mm




Example of a 72PE pulse




Example of a 106PE pulse




Example of a 74PE pulse




Example of a 3681PE pulse




837 PE distribution x=300mm y=75mm




Example of a 84PE pulse



Example of a 83PE pulse



Example of a 54PE pulse



Example of a 56PE pulse

