




1186 PE distribution x=1000mm y=75mm




Example of a 159PE pulse




Example of a 162PE pulse




Example of a 36PE pulse




Example of a 204PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 238PE pulse




Example of a 227PE pulse




Example of a 244PE pulse




Example of a 215PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 184PE pulse




Example of a 220PE pulse




Example of a 245PE pulse




Example of a 252PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 283PE pulse




Example of a 282PE pulse




Example of a 269PE pulse




Example of a 186PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 32PE pulse




Example of a 23PE pulse




Example of a 20PE pulse




Example of a 33PE pulse




1186 PE distribution x=1000mm y=75mm




1186 PE distribution x=1000mm y=75mm




Example of a 114PE pulse




Example of a 72PE pulse




Example of a 147PE pulse




Example of a 26PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 76PE pulse




Example of a 118PE pulse




Example of a 85PE pulse




Example of a 79PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 75PE pulse




Example of a 22PE pulse




Example of a 50PE pulse




Example of a 28PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 136PE pulse




Example of a 160PE pulse




Example of a 24PE pulse




Example of a 138PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 160PE pulse




Example of a 217PE pulse




Example of a 232PE pulse




Example of a 197PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 206PE pulse




Example of a 241PE pulse




Example of a 172PE pulse




Example of a 223PE pulse




1186 PE distribution x=1000mm y=75mm




Example of a 48PE pulse




Example of a 57PE pulse




Example of a 99PE pulse




Example of a 178PE pulse



1186 PE distribution x=1000mm y=75mm



1186 PE distribution x=1000mm y=75mm



1186 PE distribution x=1000mm y=75mm

