




1152 PE distribution x=1000mm y=25mm




Example of a 84PE pulse




Example of a 63PE pulse




Example of a 82PE pulse




Example of a 63PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 241PE pulse




Example of a 301PE pulse




Example of a 66PE pulse




Example of a 74PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 51PE pulse




Example of a 55PE pulse




Example of a 83PE pulse




Example of a 55PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 326PE pulse




Example of a 289PE pulse




Example of a 79PE pulse




Example of a 101PE pulse




1152 PE distribution x=1000mm y=25mm




1152 PE distribution x=1000mm y=25mm




1152 PE distribution x=1000mm y=25mm




Example of a 63PE pulse




Example of a 59PE pulse




Example of a 78PE pulse




Example of a 59PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 81PE pulse




Example of a 75PE pulse




Example of a 66PE pulse




Example of a 86PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 70PE pulse




Example of a 93PE pulse




Example of a 97PE pulse




Example of a 96PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 82PE pulse




Example of a 115PE pulse




Example of a 109PE pulse




Example of a 105PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 72PE pulse




Example of a 64PE pulse




Example of a 84PE pulse




Example of a 45PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 212PE pulse




Example of a 275PE pulse




Example of a 50PE pulse




Example of a 34PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 54PE pulse




Example of a 53PE pulse




Example of a 62PE pulse




Example of a 56PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 290PE pulse




Example of a 264PE pulse




Example of a 53PE pulse




Example of a 50PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 45PE pulse




Example of a 48PE pulse




Example of a 54PE pulse




Example of a 38PE pulse




1152 PE distribution x=1000mm y=25mm




Example of a 47PE pulse



Example of a 49PE pulse



Example of a 66PE pulse



Example of a 85PE pulse

