




# 827 PE distribution x=1500mm y=25mm




Example of a 62PE pulse




Example of a 57PE pulse




Example of a 42PE pulse




Example of a 48PE pulse




# 827 PE distribution x=1500mm y=25mm




Example of a 51PE pulse




Example of a 64PE pulse




Example of a 58PE pulse




Example of a 46PE pulse




# 827 PE distribution x=1500mm y=25mm




Example of a 64PE pulse




Example of a 71PE pulse




Example of a 67PE pulse




Example of a 79PE pulse




# 827 PE distribution x=1500mm y=25mm




Example of a 64PE pulse




Example of a 53PE pulse




Example of a 71PE pulse




Example of a 53PE pulse




# 827 PE distribution x=1500mm y=25mm




Example of a 62PE pulse




Example of a 57PE pulse




Example of a 40PE pulse




Example of a 38PE pulse




# 827 PE distribution x=1500mm y=25mm




Example of a 57PE pulse




Example of a 55PE pulse




Example of a 60PE pulse




Example of a 54PE pulse




# 827 PE distribution x=1500mm y=25mm




Example of a 63PE pulse




Example of a 73PE pulse




Example of a 71PE pulse




Example of a 89PE pulse




# 827 PE distribution x=1500mm y=25mm




Example of a 57PE pulse



Example of a 57PE pulse



Example of a 67PE pulse



Example of a 71PE pulse

