




# 1266 PE distribution x=250mm y=25mm




Example of a 87PE pulse




Example of a 118PE pulse




Example of a 111PE pulse




Example of a 87PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 293PE pulse




Example of a 327PE pulse




Example of a 185PE pulse




Example of a 192PE pulse




1266 PE distribution x=250mm y=25mm




1266 PE distribution x=250mm y=25mm




# 1266 PE distribution x=250mm y=25mm




Example of a 21PE pulse




Example of a 25PE pulse




Example of a 21PE pulse




Example of a 20PE pulse




1266 PE distribution x=250mm y=25mm




# 1266 PE distribution x=250mm y=25mm




Example of a 93PE pulse




Example of a 104PE pulse




Example of a 84PE pulse




Example of a 65PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 289PE pulse




Example of a 282PE pulse



Example of a 164PE pulse




Example of a 164PE pulse







# 1266 PE distribution x=250mm y=25mm




Example of a 59PE pulse




Example of a 79PE pulse




Example of a 67PE pulse




Example of a 53PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 208PE pulse




Example of a 195PE pulse




Example of a 138PE pulse




Example of a 115PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 142PE pulse




Example of a 151PE pulse




Example of a 51PE pulse




Example of a 46PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 76PE pulse




Example of a 108PE pulse




Example of a 162PE pulse




Example of a 193PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 66PE pulse




Example of a 68PE pulse




Example of a 97PE pulse




Example of a 76PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 205PE pulse




Example of a 173PE pulse




Example of a 283PE pulse




Example of a 231PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 56PE pulse




Example of a 51PE pulse




Example of a 56PE pulse




Example of a 45PE pulse




# 1266 PE distribution x=250mm y=25mm




Example of a 131PE pulse



Example of a 103PE pulse



Example of a 273PE pulse



Example of a 280PE pulse

