




1296 PE distribution x=2000mm y=75mm




Example of a 219PE pulse




Example of a 164PE pulse




Example of a 198PE pulse




Example of a 165PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 83PE pulse




Example of a 110PE pulse




Example of a 93PE pulse




Example of a 75PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 48PE pulse




Example of a 41PE pulse




Example of a 107PE pulse




Example of a 103PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 122PE pulse




Example of a 102PE pulse




Example of a 85PE pulse




Example of a 66PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 100PE pulse




Example of a 110PE pulse




Example of a 189PE pulse




Example of a 149PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 51PE pulse




Example of a 62PE pulse




Example of a 59PE pulse




Example of a 63PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 101PE pulse




Example of a 92PE pulse




Example of a 189PE pulse




Example of a 202PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 51PE pulse




Example of a 78PE pulse




Example of a 79PE pulse




Example of a 79PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 234PE pulse




Example of a 208PE pulse




Example of a 283PE pulse




Example of a 226PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 112PE pulse




Example of a 101PE pulse




Example of a 98PE pulse




Example of a 106PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 74PE pulse




Example of a 53PE pulse




Example of a 148PE pulse




Example of a 136PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 142PE pulse




Example of a 130PE pulse




Example of a 63PE pulse




Example of a 68PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 141PE pulse




Example of a 143PE pulse




Example of a 227PE pulse




Example of a 198PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 83PE pulse




Example of a 70PE pulse




Example of a 67PE pulse




Example of a 57PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 130PE pulse




Example of a 110PE pulse




Example of a 192PE pulse




Example of a 219PE pulse




1296 PE distribution x=2000mm y=75mm




Example of a 87PE pulse



Example of a 68PE pulse



Example of a 73PE pulse



Example of a 83PE pulse

