




1021 PE distribution x=20mm y=25mm




Example of a 87PE pulse




Example of a 73PE pulse




Example of a 66PE pulse




Example of a 62PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 110PE pulse




Example of a 119PE pulse




Example of a 177PE pulse




Example of a 184PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 42PE pulse




Example of a 52PE pulse




Example of a 59PE pulse




Example of a 50PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 99PE pulse




Example of a 101PE pulse




Example of a 85PE pulse




Example of a 71PE pulse




1021 PE distribution x=20mm y=25mm




1021 PE distribution x=20mm y=25mm




1021 PE distribution x=20mm y=25mm




Example of a 169PE pulse




Example of a 148PE pulse




Example of a 120PE pulse




Example of a 74PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 31PE pulse




Example of a 61PE pulse




Example of a 60PE pulse




Example of a 82PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 51PE pulse




Example of a 31PE pulse




Example of a 31PE pulse




Example of a 38PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 246PE pulse




Example of a 224PE pulse




Example of a 89PE pulse




Example of a 82PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 34PE pulse




Example of a 21PE pulse




Example of a 22PE pulse




Example of a 25PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 234PE pulse




Example of a 235PE pulse




Example of a 27PE pulse




Example of a 40PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 46PE pulse




Example of a 43PE pulse




Example of a 51PE pulse




Example of a 44PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 76PE pulse




Example of a 65PE pulse




Example of a 64PE pulse




Example of a 65PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 33PE pulse




Example of a 50PE pulse




Example of a 40PE pulse




Example of a 23PE pulse




1021 PE distribution x=20mm y=25mm




Example of a 20PE pulse



Example of a 41PE pulse



Example of a 32PE pulse



Example of a 39PE pulse

