




1057 PE distribution x=500mm y=75mm




Example of a 104PE pulse




Example of a 117PE pulse




Example of a 140PE pulse




Example of a 123PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 119PE pulse




Example of a 131PE pulse




Example of a 133PE pulse




Example of a 131PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 110PE pulse




Example of a 112PE pulse




Example of a 90PE pulse




Example of a 110PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 84PE pulse




Example of a 68PE pulse




Example of a 109PE pulse




Example of a 81PE pulse




1057 PE distribution x=500mm y=75mm




1057 PE distribution x=500mm y=75mm




1057 PE distribution x=500mm y=75mm




Example of a 66PE pulse




Example of a 66PE pulse




Example of a 67PE pulse




Example of a 68PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 56PE pulse




Example of a 76PE pulse




Example of a 97PE pulse




Example of a 98PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 93PE pulse




Example of a 22PE pulse




Example of a 89PE pulse




Example of a 92PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 122PE pulse




Example of a 128PE pulse




Example of a 113PE pulse




Example of a 95PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 70PE pulse




Example of a 94PE pulse




Example of a 86PE pulse




Example of a 95PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 87PE pulse




Example of a 83PE pulse




Example of a 61PE pulse




Example of a 76PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 78PE pulse




Example of a 99PE pulse




Example of a 54PE pulse




Example of a 65PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 59PE pulse




Example of a 46PE pulse




Example of a 53PE pulse




Example of a 45PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 41PE pulse




Example of a 50PE pulse




Example of a 45PE pulse




Example of a 48PE pulse




1057 PE distribution x=500mm y=75mm




Example of a 54PE pulse



Example of a 56PE pulse



Example of a 81PE pulse



Example of a 53PE pulse

