




1062 PE distribution x=1250mm y=75mm




Example of a 63PE pulse




Example of a 69PE pulse




Example of a 70PE pulse




Example of a 69PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 70PE pulse




Example of a 65PE pulse




Example of a 62PE pulse




Example of a 73PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 60PE pulse




Example of a 69PE pulse




Example of a 69PE pulse




Example of a 58PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 54PE pulse




Example of a 70PE pulse




Example of a 69PE pulse




Example of a 54PE pulse




1062 PE distribution x=1250mm y=75mm




1062 PE distribution x=1250mm y=75mm




1062 PE distribution x=1250mm y=75mm




Example of a 59PE pulse




Example of a 63PE pulse




Example of a 80PE pulse




Example of a 63PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 84PE pulse




Example of a 79PE pulse




Example of a 79PE pulse




Example of a 76PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 114PE pulse




Example of a 135PE pulse




Example of a 115PE pulse




Example of a 142PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 119PE pulse




Example of a 111PE pulse




Example of a 66PE pulse




Example of a 73PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 62PE pulse




Example of a 73PE pulse




Example of a 73PE pulse




Example of a 72PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 67PE pulse




Example of a 68PE pulse




Example of a 61PE pulse




Example of a 60PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 83PE pulse




Example of a 80PE pulse




Example of a 60PE pulse




Example of a 55PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 46PE pulse




Example of a 53PE pulse




Example of a 65PE pulse




Example of a 76PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 53PE pulse




Example of a 67PE pulse




Example of a 74PE pulse




Example of a 70PE pulse




1062 PE distribution x=1250mm y=75mm




Example of a 95PE pulse



Example of a 91PE pulse



Example of a 102PE pulse



Example of a 90PE pulse

