




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




Example of a 24PE pulse




Example of a 23PE pulse




Example of a 31PE pulse




Example of a 25PE pulse




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




Example of a 20PE pulse




Example of a 32PE pulse




Example of a 27PE pulse




Example of a 29PE pulse




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm




1140 PE distribution x=1000mm y=75mm



1140 PE distribution x=1000mm y=75mm



1140 PE distribution x=1000mm y=75mm



1140 PE distribution x=1000mm y=75mm

