




1256 PE distribution x=2250mm y=75mm




Example of a 246PE pulse




Example of a 233PE pulse




Example of a 96PE pulse




Example of a 73PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 80PE pulse




Example of a 65PE pulse




Example of a 64PE pulse




Example of a 64PE pulse




1256 PE distribution x=2250mm y=75mm




1256 PE distribution x=2250mm y=75mm




1256 PE distribution x=2250mm y=75mm




Example of a 21PE pulse




Example of a 24PE pulse




Example of a 21PE pulse




Example of a 111PE pulse




1256 PE distribution x=2250mm y=75mm




1256 PE distribution x=2250mm y=75mm




Example of a 130PE pulse




Example of a 131PE pulse




Example of a 75PE pulse




Example of a 80PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 51PE pulse




Example of a 68PE pulse




Example of a 91PE pulse




Example of a 84PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 304PE pulse




Example of a 270PE pulse




Example of a 120PE pulse




Example of a 96PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 102PE pulse




Example of a 84PE pulse




Example of a 93PE pulse




Example of a 76PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 286PE pulse




Example of a 246PE pulse




Example of a 51PE pulse




Example of a 41PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 65PE pulse




Example of a 54PE pulse




Example of a 66PE pulse




Example of a 85PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 309PE pulse




Example of a 336PE pulse




Example of a 193PE pulse




Example of a 211PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 126PE pulse




Example of a 94PE pulse




Example of a 124PE pulse




Example of a 101PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 172PE pulse




Example of a 178PE pulse




Example of a 145PE pulse




Example of a 127PE pulse




1256 PE distribution x=2250mm y=75mm




Example of a 67PE pulse



Example of a 55PE pulse



Example of a 138PE pulse



Example of a 132PE pulse

