




1154 PE distribution x=0mm y=0mm




Example of a 87PE pulse




Example of a 71PE pulse




Example of a 56PE pulse




Example of a 77PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 61PE pulse




Example of a 75PE pulse




Example of a 85PE pulse




Example of a 71PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 48PE pulse




Example of a 74PE pulse




Example of a 63PE pulse




Example of a 65PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 67PE pulse




Example of a 62PE pulse




Example of a 104PE pulse




Example of a 80PE pulse




1154 PE distribution x=0mm y=0mm




1154 PE distribution x=0mm y=0mm




1154 PE distribution x=0mm y=0mm




Example of a 92PE pulse




Example of a 72PE pulse




Example of a 48PE pulse




Example of a 73PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 53PE pulse




Example of a 62PE pulse




Example of a 107PE pulse




Example of a 87PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 92PE pulse




Example of a 74PE pulse




Example of a 79PE pulse




Example of a 98PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 116PE pulse




Example of a 95PE pulse




Example of a 144PE pulse




Example of a 112PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 67PE pulse




Example of a 56PE pulse




Example of a 48PE pulse




Example of a 49PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 52PE pulse




Example of a 61PE pulse




Example of a 54PE pulse




Example of a 48PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 43PE pulse




Example of a 48PE pulse




Example of a 52PE pulse




Example of a 47PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 81PE pulse




Example of a 67PE pulse




Example of a 80PE pulse




Example of a 79PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 72PE pulse




Example of a 58PE pulse




Example of a 48PE pulse




Example of a 64PE pulse




1154 PE distribution x=0mm y=0mm




Example of a 59PE pulse



Example of a 69PE pulse



Example of a 98PE pulse



Example of a 63PE pulse

