




808 PE distribution x=1250mm y=25mm




Example of a 32PE pulse




Example of a 47PE pulse




Example of a 63PE pulse




Example of a 73PE pulse




808 PE distribution x=1250mm y=25mm




Example of a 54PE pulse




Example of a 70PE pulse




Example of a 61PE pulse




Example of a 55PE pulse




808 PE distribution x=1250mm y=25mm




Example of a 80PE pulse




Example of a 75PE pulse




Example of a 48PE pulse




Example of a 51PE pulse




808 PE distribution x=1250mm y=25mm




Example of a 66PE pulse




Example of a 79PE pulse




Example of a 78PE pulse




Example of a 79PE pulse




808 PE distribution x=1250mm y=25mm




Example of a 50PE pulse




Example of a 53PE pulse




Example of a 96PE pulse




Example of a 102PE pulse




808 PE distribution x=1250mm y=25mm




Example of a 64PE pulse




Example of a 79PE pulse




Example of a 62PE pulse




Example of a 63PE pulse




808 PE distribution x=1250mm y=25mm




Example of a 91PE pulse




Example of a 92PE pulse




Example of a 71PE pulse




Example of a 64PE pulse




808 PE distribution x=1250mm y=25mm




Example of a 76PE pulse



Example of a 83PE pulse



Example of a 80PE pulse



Example of a 81PE pulse

