




# 1253 PE distribution x=1500mm y=75mm




Example of a 80PE pulse




Example of a 81PE pulse




Example of a 104PE pulse




Example of a 97PE pulse




# 1253 PE distribution x=1500mm y=75mm




Example of a 76PE pulse




Example of a 80PE pulse




Example of a 211PE pulse




Example of a 210PE pulse




1253 PE distribution x=1500mm y=75mm




1253 PE distribution x=1500mm y=75mm




# 1253 PE distribution x=1500mm y=75mm




Example of a 20PE pulse




Example of a 21PE pulse




Example of a 20PE pulse




Example of a 21PE pulse




# 1253 PE distribution x=1500mm y=75mm




# 1253 PE distribution x=1500mm y=75mm




Example of a 73PE pulse




Example of a 59PE pulse




Example of a 66PE pulse




Example of a 59PE pulse




# 1253 PE distribution x=1500mm y=75mm




Example of a 60PE pulse




Example of a 43PE pulse



Example of a 209PE pulse




Example of a 222PE pulse







# 1253 PE distribution x=1500mm y=75mm




Example of a 105PE pulse




Example of a 83PE pulse




Example of a 71PE pulse




Example of a 82PE pulse




# 1253 PE distribution x=1500mm y=75mm




Example of a 63PE pulse




Example of a 75PE pulse




Example of a 187PE pulse




Example of a 205PE pulse




# 1253 PE distribution x=1500mm y=75mm




Example of a 159PE pulse




Example of a 111PE pulse




Example of a 57PE pulse




Example of a 64PE pulse




1253 PE distribution x=1500mm y=75mm




Example of a 86PE pulse




Example of a 89PE pulse




Example of a 161PE pulse




Example of a 163PE pulse




# 1253 PE distribution x=1500mm y=75mm




Example of a 115PE pulse




Example of a 96PE pulse




Example of a 77PE pulse




Example of a 108PE pulse




# 1253 PE distribution x=1500mm y=75mm




Example of a 69PE pulse




Example of a 96PE pulse




Example of a 74PE pulse




Example of a 327PE pulse




# 1253 PE distribution x=1500mm y=75mm




Example of a 73PE pulse




Example of a 76PE pulse




Example of a 63PE pulse




Example of a 61PE pulse




# 1253 PE distribution x=1500mm y=75mm




Example of a 53PE pulse



Example of a 56PE pulse



Example of a 241PE pulse



Example of a 223PE pulse

