




834 PE distribution x=750mm y=25mm




Example of a 35PE pulse




Example of a 38PE pulse




Example of a 40PE pulse




Example of a 47PE pulse




834 PE distribution x=750mm y=25mm




Example of a 52PE pulse




Example of a 41PE pulse




Example of a 67PE pulse




Example of a 49PE pulse




834 PE distribution x=750mm y=25mm




Example of a 57PE pulse




Example of a 42PE pulse




Example of a 51PE pulse




Example of a 49PE pulse




834 PE distribution x=750mm y=25mm




Example of a 63PE pulse




Example of a 71PE pulse




Example of a 56PE pulse




Example of a 52PE pulse




834 PE distribution x=750mm y=25mm




Example of a 35PE pulse




Example of a 43PE pulse




Example of a 66PE pulse




Example of a 68PE pulse




834 PE distribution x=750mm y=25mm




Example of a 77PE pulse




Example of a 65PE pulse




Example of a 67PE pulse




Example of a 60PE pulse




834 PE distribution x=750mm y=25mm




Example of a 67PE pulse




Example of a 79PE pulse




Example of a 63PE pulse




Example of a 66PE pulse




834 PE distribution x=750mm y=25mm




Example of a 75PE pulse



Example of a 85PE pulse



Example of a 97PE pulse



Example of a 88PE pulse

