




# 805 PE distribution x=750mm y=75mm




Example of a 25PE pulse




Example of a 33PE pulse




Example of a 34PE pulse




Example of a 40PE pulse




# 805 PE distribution x=750mm y=75mm




Example of a 65PE pulse




Example of a 67PE pulse




Example of a 40PE pulse




Example of a 60PE pulse




# 805 PE distribution x=750mm y=75mm




Example of a 66PE pulse




Example of a 69PE pulse




Example of a 58PE pulse




Example of a 61PE pulse




# 805 PE distribution x=750mm y=75mm




Example of a 41PE pulse




Example of a 56PE pulse




Example of a 69PE pulse




Example of a 56PE pulse




# 805 PE distribution x=750mm y=75mm




Example of a 58PE pulse




Example of a 46PE pulse




Example of a 58PE pulse




Example of a 57PE pulse




# 805 PE distribution x=750mm y=75mm




Example of a 90PE pulse




Example of a 81PE pulse




Example of a 60PE pulse




Example of a 63PE pulse




# 805 PE distribution x=750mm y=75mm




Example of a 90PE pulse




Example of a 83PE pulse




Example of a 78PE pulse




Example of a 67PE pulse




# 805 PE distribution x=750mm y=75mm




Example of a 76PE pulse



Example of a 61PE pulse



Example of a 80PE pulse



Example of a 71PE pulse

