




803 PE distribution x=500mm y=25mm




Example of a 39PE pulse




Example of a 30PE pulse




Example of a 55PE pulse




Example of a 71PE pulse




803 PE distribution x=500mm y=25mm




Example of a 63PE pulse




Example of a 74PE pulse




Example of a 44PE pulse




Example of a 51PE pulse




803 PE distribution x=500mm y=25mm




Example of a 68PE pulse




Example of a 52PE pulse




Example of a 47PE pulse




Example of a 51PE pulse




803 PE distribution x=500mm y=25mm




Example of a 62PE pulse




Example of a 45PE pulse




Example of a 44PE pulse




Example of a 69PE pulse




803 PE distribution x=500mm y=25mm




Example of a 74PE pulse




Example of a 65PE pulse




Example of a 86PE pulse




Example of a 85PE pulse




803 PE distribution x=500mm y=25mm




Example of a 116PE pulse




Example of a 105PE pulse




Example of a 65PE pulse




Example of a 102PE pulse




803 PE distribution x=500mm y=25mm




Example of a 86PE pulse




Example of a 81PE pulse




Example of a 86PE pulse




Example of a 74PE pulse




803 PE distribution x=500mm y=25mm




Example of a 87PE pulse



Example of a 83PE pulse



Example of a 86PE pulse



Example of a 86PE pulse

