




1260 PE distribution x=1500mm y=25mm




Example of a 69PE pulse




Example of a 84PE pulse




Example of a 77PE pulse




Example of a 79PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 89PE pulse




Example of a 99PE pulse




Example of a 33PE pulse




Example of a 29PE pulse




1260 PE distribution x=1500mm y=25mm




1260 PE distribution x=1500mm y=25mm




1260 PE distribution x=1500mm y=25mm




Example of a 21PE pulse




Example of a 22PE pulse




Example of a 23PE pulse




Example of a 21PE pulse




1260 PE distribution x=1500mm y=25mm




1260 PE distribution x=1500mm y=25mm




Example of a 74PE pulse




Example of a 66PE pulse




Example of a 139PE pulse




Example of a 156PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 149PE pulse




Example of a 147PE pulse




Example of a 211PE pulse




Example of a 235PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 64PE pulse




Example of a 59PE pulse




Example of a 99PE pulse




Example of a 74PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 339PE pulse




Example of a 332PE pulse




Example of a 22PE pulse




Example of a 31PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 66PE pulse




Example of a 48PE pulse




Example of a 61PE pulse




Example of a 57PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 67PE pulse




Example of a 76PE pulse




Example of a 217PE pulse




Example of a 263PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 81PE pulse




Example of a 101PE pulse




Example of a 85PE pulse




Example of a 77PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 349PE pulse




Example of a 29PE pulse




Example of a 49PE pulse




Example of a 48PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 69PE pulse




Example of a 82PE pulse




Example of a 132PE pulse




Example of a 140PE pulse




1260 PE distribution x=1500mm y=25mm




Example of a 165PE pulse



Example of a 140PE pulse



Example of a 249PE pulse



Example of a 244PE pulse

