




1013 PE distribution x=200mm y=75mm




Example of a 241PE pulse




Example of a 251PE pulse




Example of a 156PE pulse




Example of a 120PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 125PE pulse




Example of a 123PE pulse




Example of a 109PE pulse




Example of a 139PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 87PE pulse




Example of a 85PE pulse




Example of a 225PE pulse




Example of a 255PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 105PE pulse




Example of a 102PE pulse




Example of a 85PE pulse




Example of a 80PE pulse




1013 PE distribution x=200mm y=75mm




1013 PE distribution x=200mm y=75mm




1013 PE distribution x=200mm y=75mm




Example of a 74PE pulse




Example of a 63PE pulse




Example of a 23PE pulse




Example of a 30PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 175PE pulse




Example of a 78PE pulse




Example of a 101PE pulse




Example of a 84PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 157PE pulse




Example of a 162PE pulse




Example of a 254PE pulse




Example of a 238PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 55PE pulse




Example of a 70PE pulse




Example of a 63PE pulse




Example of a 67PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 137PE pulse




Example of a 150PE pulse




Example of a 196PE pulse




Example of a 170PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 46PE pulse




Example of a 36PE pulse




Example of a 45PE pulse




Example of a 36PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 251PE pulse




Example of a 255PE pulse




Example of a 23PE pulse




Example of a 21PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 65PE pulse




Example of a 60PE pulse




Example of a 65PE pulse




Example of a 70PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 187PE pulse




Example of a 199PE pulse




Example of a 194PE pulse




Example of a 209PE pulse




1013 PE distribution x=200mm y=75mm




Example of a 48PE pulse



Example of a 33PE pulse



Example of a 46PE pulse



Example of a 48PE pulse

