




809 PE distribution x=1250mm y=75mm




Example of a 48PE pulse




Example of a 49PE pulse




Example of a 43PE pulse




Example of a 50PE pulse




809 PE distribution x=1250mm y=75mm




Example of a 69PE pulse




Example of a 57PE pulse




Example of a 72PE pulse




Example of a 65PE pulse




809 PE distribution x=1250mm y=75mm




Example of a 51PE pulse




Example of a 62PE pulse




Example of a 78PE pulse




Example of a 66PE pulse




809 PE distribution x=1250mm y=75mm




Example of a 55PE pulse




Example of a 59PE pulse




Example of a 55PE pulse




Example of a 60PE pulse




809 PE distribution x=1250mm y=75mm




Example of a 52PE pulse




Example of a 56PE pulse




Example of a 58PE pulse




Example of a 49PE pulse




809 PE distribution x=1250mm y=75mm




Example of a 86PE pulse




Example of a 72PE pulse




Example of a 74PE pulse




Example of a 101PE pulse




809 PE distribution x=1250mm y=75mm




Example of a 45PE pulse




Example of a 63PE pulse




Example of a 53PE pulse




Example of a 83PE pulse




809 PE distribution x=1250mm y=75mm




Example of a 78PE pulse



Example of a 45PE pulse



Example of a 73PE pulse



Example of a 62PE pulse

