




814 PE distribution x=1750mm y=75mm




Example of a 42PE pulse




Example of a 42PE pulse




Example of a 35PE pulse




Example of a 60PE pulse




814 PE distribution x=1750mm y=75mm




Example of a 55PE pulse




Example of a 47PE pulse




Example of a 64PE pulse




Example of a 80PE pulse




814 PE distribution x=1750mm y=75mm




Example of a 57PE pulse




Example of a 79PE pulse




Example of a 78PE pulse




Example of a 72PE pulse




814 PE distribution x=1750mm y=75mm




Example of a 74PE pulse




Example of a 71PE pulse




Example of a 65PE pulse




Example of a 69PE pulse




814 PE distribution x=1750mm y=75mm




Example of a 46PE pulse




Example of a 37PE pulse




Example of a 51PE pulse




Example of a 62PE pulse




814 PE distribution x=1750mm y=75mm




Example of a 49PE pulse




Example of a 55PE pulse




Example of a 56PE pulse




Example of a 58PE pulse




814 PE distribution x=1750mm y=75mm




Example of a 59PE pulse




Example of a 61PE pulse




Example of a 61PE pulse




Example of a 67PE pulse




814 PE distribution x=1750mm y=75mm




Example of a 49PE pulse



Example of a 55PE pulse



Example of a 51PE pulse



Example of a 65PE pulse

