




1264 PE distribution x=500mm y=25mm




Example of a 92PE pulse




Example of a 89PE pulse




Example of a 103PE pulse




Example of a 86PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 174PE pulse




Example of a 141PE pulse




Example of a 110PE pulse




Example of a 105PE pulse




1264 PE distribution x=500mm y=25mm




1264 PE distribution x=500mm y=25mm




1264 PE distribution x=500mm y=25mm




Example of a 21PE pulse




Example of a 21PE pulse




Example of a 20PE pulse




Example of a 20PE pulse




1264 PE distribution x=500mm y=25mm




1264 PE distribution x=500mm y=25mm




Example of a 101PE pulse




Example of a 102PE pulse




Example of a 80PE pulse




Example of a 66PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 105PE pulse




Example of a 134PE pulse




Example of a 46PE pulse




Example of a 46PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 59PE pulse




Example of a 52PE pulse




Example of a 92PE pulse




Example of a 67PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 130PE pulse




Example of a 112PE pulse




Example of a 63PE pulse




Example of a 80PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 49PE pulse




Example of a 55PE pulse




Example of a 64PE pulse




Example of a 43PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 83PE pulse




Example of a 98PE pulse




Example of a 133PE pulse




Example of a 166PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 59PE pulse




Example of a 69PE pulse




Example of a 70PE pulse




Example of a 85PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 85PE pulse




Example of a 79PE pulse




Example of a 73PE pulse




Example of a 80PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 72PE pulse




Example of a 67PE pulse




Example of a 67PE pulse




Example of a 54PE pulse




1264 PE distribution x=500mm y=25mm




Example of a 82PE pulse



Example of a 84PE pulse



Example of a 34PE pulse



Example of a 36PE pulse

