




1263 PE distribution x=750mm y=25mm




Example of a 104PE pulse




Example of a 100PE pulse




Example of a 111PE pulse




Example of a 114PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 200PE pulse




Example of a 194PE pulse




Example of a 55PE pulse




Example of a 81PE pulse




1263 PE distribution x=750mm y=25mm




1263 PE distribution x=750mm y=25mm




1263 PE distribution x=750mm y=25mm




Example of a 24PE pulse




Example of a 21PE pulse




Example of a 24PE pulse




Example of a 29PE pulse




1263 PE distribution x=750mm y=25mm




1263 PE distribution x=750mm y=25mm




Example of a 97PE pulse




Example of a 78PE pulse




Example of a 86PE pulse




Example of a 77PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 65PE pulse




Example of a 70PE pulse




Example of a 71PE pulse




Example of a 106PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 82PE pulse




Example of a 65PE pulse




Example of a 68PE pulse




Example of a 91PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 126PE pulse




Example of a 40PE pulse




Example of a 71PE pulse




Example of a 266PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 57PE pulse




Example of a 56PE pulse




Example of a 51PE pulse




Example of a 51PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 43PE pulse




Example of a 57PE pulse




Example of a 273PE pulse




Example of a 251PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 71PE pulse




Example of a 68PE pulse




Example of a 67PE pulse




Example of a 67PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 145PE pulse




Example of a 74PE pulse




Example of a 59PE pulse




Example of a 392PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 75PE pulse




Example of a 69PE pulse




Example of a 56PE pulse




Example of a 48PE pulse




1263 PE distribution x=750mm y=25mm




Example of a 38PE pulse



Example of a 54PE pulse



Example of a 40PE pulse



Example of a 64PE pulse

