




1292 PE distribution x=1000mm y=75mm




Example of a 87PE pulse




Example of a 95PE pulse




Example of a 217PE pulse




Example of a 211PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 96PE pulse




Example of a 97PE pulse




Example of a 86PE pulse




Example of a 76PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 70PE pulse




Example of a 65PE pulse




Example of a 246PE pulse




Example of a 230PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 75PE pulse




Example of a 72PE pulse




Example of a 58PE pulse




Example of a 74PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 70PE pulse




Example of a 56PE pulse




Example of a 188PE pulse




Example of a 182PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 83PE pulse




Example of a 68PE pulse




Example of a 73PE pulse




Example of a 68PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 54PE pulse




Example of a 50PE pulse




Example of a 236PE pulse




Example of a 253PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 109PE pulse




Example of a 94PE pulse




Example of a 67PE pulse




Example of a 81PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 81PE pulse




Example of a 53PE pulse




Example of a 200PE pulse




Example of a 151PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 81PE pulse




Example of a 91PE pulse




Example of a 79PE pulse




Example of a 80PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 71PE pulse




Example of a 51PE pulse




Example of a 207PE pulse




Example of a 174PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 66PE pulse




Example of a 59PE pulse




Example of a 42PE pulse




Example of a 50PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 61PE pulse




Example of a 42PE pulse




Example of a 150PE pulse




Example of a 171PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 67PE pulse




Example of a 67PE pulse




Example of a 75PE pulse




Example of a 61PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 58PE pulse




Example of a 53PE pulse




Example of a 187PE pulse




Example of a 195PE pulse




1292 PE distribution x=1000mm y=75mm




Example of a 97PE pulse



Example of a 87PE pulse



Example of a 56PE pulse



Example of a 54PE pulse

