




1175 PE distribution x=1000mm y=75mm




Example of a 207PE pulse




Example of a 182PE pulse




Example of a 89PE pulse




Example of a 77PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 91PE pulse




Example of a 82PE pulse




Example of a 91PE pulse




Example of a 67PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 155PE pulse




Example of a 129PE pulse




Example of a 95PE pulse




Example of a 80PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 100PE pulse




Example of a 80PE pulse





Example of a 94PE pulse




Example of a 79PE pulse




1175 PE distribution x=1000mm y=75mm




1175 PE distribution x=1000mm y=75mm




1175 PE distribution x=1000mm y=75mm




Example of a 120PE pulse




Example of a 91PE pulse




Example of a 132PE pulse




Example of a 86PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 130PE pulse




Example of a 88PE pulse




Example of a 172PE pulse




Example of a 151PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 173PE pulse




Example of a 168PE pulse




Example of a 170PE pulse




Example of a 138PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 204PE pulse




Example of a 154PE pulse




Example of a 142PE pulse




Example of a 133PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 184PE pulse




Example of a 187PE pulse




Example of a 78PE pulse




Example of a 75PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 71PE pulse




Example of a 56PE pulse




Example of a 64PE pulse




Example of a 65PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 135PE pulse




Example of a 106PE pulse




Example of a 76PE pulse




Example of a 76PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 93PE pulse




Example of a 94PE pulse




Example of a 92PE pulse




Example of a 93PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 104PE pulse




Example of a 106PE pulse




Example of a 139PE pulse




Example of a 87PE pulse




1175 PE distribution x=1000mm y=75mm




Example of a 122PE pulse



Example of a 92PE pulse



Example of a 120PE pulse



Example of a 136PE pulse

