




712 PE distribution x=45mm y=25mm




Example of a 65PE pulse




Example of a 60PE pulse




Example of a 35PE pulse




Example of a 39PE pulse




712 PE distribution x=45mm y=25mm




Example of a 39PE pulse




Example of a 45PE pulse




Example of a 53PE pulse




Example of a 50PE pulse




712 PE distribution x=45mm y=25mm




Example of a 39PE pulse




Example of a 39PE pulse




Example of a 56PE pulse




Example of a 68PE pulse




712 PE distribution x=45mm y=25mm




Example of a 30PE pulse




Example of a 35PE pulse




Example of a 49PE pulse




Example of a 27PE pulse




712 PE distribution x=45mm y=25mm




Example of a 44PE pulse




Example of a 46PE pulse




Example of a 51PE pulse




Example of a 66PE pulse




712 PE distribution x=45mm y=25mm




Example of a 100PE pulse




Example of a 35PE pulse




Example of a 51PE pulse




Example of a 52PE pulse




712 PE distribution x=45mm y=25mm




Example of a 88PE pulse




Example of a 98PE pulse




Example of a 26PE pulse




Example of a 23PE pulse




712 PE distribution x=45mm y=25mm




Example of a 63PE pulse




Example of a 180PE pulse




Example of a 162PE pulse




Example of a 222PE pulse




712 PE distribution x=45mm y=25mm




Example of a 99PE pulse




Example of a 105PE pulse




Example of a 64PE pulse




Example of a 102PE pulse




712 PE distribution x=45mm y=25mm




Example of a 74PE pulse




Example of a 80PE pulse




Example of a 96PE pulse




Example of a 100PE pulse




712 PE distribution x=45mm y=25mm




Example of a 57PE pulse




Example of a 279PE pulse




Example of a 78PE pulse




Example of a 123PE pulse




712 PE distribution x=45mm y=25mm




Example of a 74PE pulse




Example of a 82PE pulse




Example of a 78PE pulse




Example of a 62PE pulse




712 PE distribution x=45mm y=25mm




Example of a 68PE pulse




Example of a 67PE pulse




Example of a 96PE pulse




Example of a 99PE pulse




712 PE distribution x=45mm y=25mm




Example of a 45PE pulse




Example of a 47PE pulse




Example of a 87PE pulse




Example of a 74PE pulse




712 PE distribution x=45mm y=25mm




Example of a 39PE pulse




Example of a 44PE pulse




Example of a 33PE pulse




Example of a 49PE pulse




712 PE distribution x=45mm y=25mm




Example of a 264PE pulse



Example of a 242PE pulse



Example of a 33PE pulse



Example of a 23PE pulse

