




1053 PE distribution x=50mm y=75mm




Example of a 171PE pulse




Example of a 159PE pulse




Example of a 104PE pulse




Example of a 79PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 132PE pulse




Example of a 109PE pulse




Example of a 70PE pulse




Example of a 73PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 133PE pulse




Example of a 126PE pulse




Example of a 67PE pulse




Example of a 58PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 83PE pulse




Example of a 80PE pulse




Example of a 90PE pulse




Example of a 84PE pulse




1053 PE distribution x=50mm y=75mm




1053 PE distribution x=50mm y=75mm




1053 PE distribution x=50mm y=75mm




Example of a 50PE pulse




Example of a 40PE pulse




Example of a 82PE pulse




Example of a 93PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 92PE pulse




Example of a 102PE pulse




Example of a 145PE pulse




Example of a 101PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 191PE pulse




Example of a 206PE pulse




Example of a 66PE pulse




Example of a 51PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 112PE pulse




Example of a 77PE pulse




Example of a 66PE pulse




Example of a 82PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 130PE pulse




Example of a 103PE pulse




Example of a 47PE pulse




Example of a 35PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 52PE pulse




Example of a 53PE pulse




Example of a 35PE pulse




Example of a 30PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 54PE pulse




Example of a 77PE pulse




Example of a 27PE pulse




Example of a 30PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 34PE pulse




Example of a 43PE pulse




Example of a 42PE pulse




Example of a 37PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 27PE pulse




Example of a 40PE pulse




Example of a 34PE pulse




Example of a 20PE pulse




1053 PE distribution x=50mm y=75mm




Example of a 68PE pulse



Example of a 49PE pulse



Example of a 80PE pulse



Example of a 63PE pulse

