




797 PE distribution x=100mm y=75mm




Example of a 66PE pulse




Example of a 59PE pulse




Example of a 21PE pulse




Example of a 32PE pulse




797 PE distribution x=100mm y=75mm




Example of a 97PE pulse




Example of a 85PE pulse




Example of a 42PE pulse




Example of a 37PE pulse




797 PE distribution x=100mm y=75mm




Example of a 117PE pulse




Example of a 121PE pulse




Example of a 31PE pulse




Example of a 46PE pulse




797 PE distribution x=100mm y=75mm




Example of a 134PE pulse




Example of a 126PE pulse




Example of a 47PE pulse




Example of a 34PE pulse




797 PE distribution x=100mm y=75mm




Example of a 124PE pulse




Example of a 121PE pulse




Example of a 55PE pulse




Example of a 63PE pulse




797 PE distribution x=100mm y=75mm




Example of a 178PE pulse




Example of a 154PE pulse




Example of a 77PE pulse




Example of a 54PE pulse




797 PE distribution x=100mm y=75mm




Example of a 220PE pulse




Example of a 211PE pulse




Example of a 60PE pulse




Example of a 88PE pulse




797 PE distribution x=100mm y=75mm




Example of a 248PE pulse



Example of a 230PE pulse



Example of a 68PE pulse



Example of a 63PE pulse

