




1330 PE distribution x=2000mm y=75mm




Example of a 35PE pulse




Example of a 37PE pulse




Example of a 88PE pulse




Example of a 74PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 108PE pulse




Example of a 103PE pulse




Example of a 65PE pulse




Example of a 90PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 128PE pulse




Example of a 88PE pulse




Example of a 90PE pulse




Example of a 99PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 42PE pulse




Example of a 45PE pulse




Example of a 64PE pulse




Example of a 48PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 130PE pulse




Example of a 126PE pulse




Example of a 183PE pulse




Example of a 144PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 36PE pulse




Example of a 34PE pulse




Example of a 81PE pulse




Example of a 69PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 55PE pulse




Example of a 40PE pulse




Example of a 155PE pulse




Example of a 129PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 29PE pulse




Example of a 44PE pulse




Example of a 90PE pulse




Example of a 100PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 37PE pulse




Example of a 36PE pulse




Example of a 112PE pulse




Example of a 94PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 121PE pulse




Example of a 126PE pulse




Example of a 84PE pulse




Example of a 89PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 141PE pulse




Example of a 118PE pulse




Example of a 107PE pulse




Example of a 108PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 62PE pulse




Example of a 46PE pulse




Example of a 49PE pulse




Example of a 50PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 169PE pulse




Example of a 171PE pulse




Example of a 223PE pulse




Example of a 176PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 47PE pulse




Example of a 45PE pulse




Example of a 111PE pulse




Example of a 102PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 44PE pulse




Example of a 41PE pulse




Example of a 103PE pulse




Example of a 107PE pulse




1330 PE distribution x=2000mm y=75mm




Example of a 47PE pulse



Example of a 55PE pulse



Example of a 52PE pulse



Example of a 99PE pulse

